

Communication Networks 2

Mobile networks

Gusztáv Adamis


BME TMIT

2019




Earth surface mobile networks

- Cellular concept
- Size of a cell?
 - Geography
 - Frequency
 - ~900 MHz – 30-35 km
 - Follow the surface of the Earth more or less
 - ~1800 MHz – 2-3 km
 - Straight propagation
 - Transmission power
 - Height of transmitter (tower)
 - Traffic (!!)
- Advantages of small cells:
 - small transmitter power enough
 - minimisation of physiological risk
 - smaller power consumption
 - higher traffic density
- Disadvantages of small cells :
 - lot of base stations needed
 - more expensive



Earth surface mobile networks

- Same frequency cannot be used in neighbouring cells – interference
 - 4 frequency set required as a minimum
 - Transmission power is large enough to cause interference in the second neighbouring cell
 - Frequency range is divided into 7 parts
 - This is only theoretical – in practice more complicated situations (base station in the „corner” of the cell, cell divided into several sectors, cells of different size, geographical circumstances, etc.)



1G systems

- 1G: first generation mobile telecommunication systems
 - End of 1970s / beginning of 1980s
 - Analogue systems
 - Lot of not compatible systems
 - E.g.: NMT (Nordic Mobile Telephone System)
 - Scandinavia since 1981
 - In Hungary 1990-2003 (Westel 0660)
 - Typically around 450 MHz frequency
 - Relatively large cells, with 30-50 km of diameter
 - Poor voice transmission quality, few services
 - More examples for 1G systems:
 - USA: Advanced Mobile Phone Service (AMPS),
 - GB: Total Access Communication System (TACS)
 - Germany: B-Network (C450)



- World-wide spread, because:
 - research-development in proper time, quickly (4 years)
 - open, improvable standard (ETSI)
 - in Europe uniform from the beginning (not in USA ☹)
 - global system (roaming)
 - concept of SIM card is attractive (data of subscribers – equipment-independent)
 - only the caller pays (in USA both parties)
 - pre-paid (later from phase 2)
 - 900 MHz: countrywide coverage possible
- Incremental development:
 - phase 1 (1991)
 - voice transmission, SIM concept, SMS, roaming, encryption of voice, 9.6 kbps data transmission
 - phase 2 (1995)
 - backward compatibility, calling number presentation, call hold, call waiting, conference call, half rate (speed) codec, etc.
 - phase 2+ (1998)
 - mainly improvement in data transmission (HSCSD, EDGE, GPRS), push-to-talk, virtual private networks, improvement of SIM, enhanced codecs, etc.


GSM

- Digital transmission:
 - voice codec in terminal
 - integrated services network: voice + data transmission
- Radiation output: max. 2W
 - Adaptive: the terminal transmits with the possibly minimal power
 - Less frequently to charge the battery
 - Minimisation of physiological risk
 - Less influence on neighbouring cells
- Diameter of cells: 0,5 – 35 km


GSM

- Radio access: FDMA+TDMA (Frequency/Time Division Multiple Access)
- GSM 900 (Primary-GSM, P-GSM)
 - mobile station (uplink): 890-915 MHz,
 - base station (downlink) 935-960 MHz
 - the smaller frequency suffers smaller attenuation, so it requires less power -> mobiles (uplink traffic) have the smaller frequency band
 - 1 band = 25 MHz, 1 carrier = 200 kHz: 124 carriers (FDMA)
 - shared among service providers
 - in a country with 4 providers: appr. 30 frequencies/service provider in this band
 - 8 time slots/carrier (TDMA)
 - $(30/10)*8 \approx 24$ channels / cell
 - 10: typically ≈ 10 different frequencies used in cells (more realistic than 7 as we could see on slide 3)
 - with Half Rate encoding: twice as much

FDMA – TDMA access



FDMA – TDMA access




GSM

- GSM 1800
 - Mobile: 1710-1785 MHz, base station: 1805-1880 MHz
 - 1 band = 75 MHz (three times larger capacity)
 - BUT: worse wave propagation
 - propagates straight
 - attenuates more quickly
 - Not (so...) suitable for countrywide coverage, only for small cells (where the traffic is high)
- Several other bands: (not to learn, but interesting)
 - Extended-GSM 900, E-GSM: +10 MHz/direction: +50 carriers
 - R-GSM: Railways GSM: 876-880/921-925 MHz
 - GSM 1900: 1850-1910/1930-1990 MHz (USA)
 - GSM 850: 824-849/869-894 MHz (USA)
- Dual band equipment: automatically select/change frequency range
 - three band (900/1800/1900) and four band equipment (850/900/1800/1900)

GSM handover/handoff



- GSM: circuit switching
- When the mobile station enters an other cell: handover (handoff)
 - Continuous connection
 - Mobile station: measures, when the signal of the neighbouring cell is stronger
 - Network controls, with the help of mobile station: network asks the mobile station to send signal strength info, but the decision is made by the network
 - the network can postpone the cell change if the „new” cell is overloaded

Architecture of GSM networks (PLMN)



Mobile Station

- MS – Mobile Station
- ME – Mobile Equipment
- Subscriber Identity Module („SIM card”)
 - Identifiers
 - Authentication
 - Ciphering
 - User data (phone book)



Base Station Subsystem (BSS)

□ Base Transceiver Station (BTS)

- One or more elementary transmitter/receiver
- Transcoder/Transmission and Rate Adapter Unit, TRAU
 - FR, HR, EFR codec \Leftrightarrow 64 kbps PCM
 - Full Rate (13 kbps), Half Rate (5.6 kbps), Enhanced Full Rate (12.2 kbps, but better than FR)
 - Rate adaptation also at data transmission: 14.4 kbps \Leftrightarrow 64 kbps

□ Base Station Controller (BSC)

- Controls one or *more* BTSs
- Radio channel assignment
- Handover control

Network and Switching Subsystem

- Mobile Switching Centre (MSC)
 - A digital switch
 - With mobile-specific extensions
 - authentication
 - location management (VLR)
 - inter-BSC handover
 - roaming
- Visitor Location Register (VLR)
 - Always integrated with MSC
 - Stores temporarily some parts of the HLR info about the currently served mobile stations
- Home Location Register (HLR)
 - Subscriber data, subscription information (services), current location
 - One HLR in every network
- Authentication Centre (AuC)
 - Typically integrated with HLR
 - It verifies that the subscriber is the same in reality as he is proposed to be

GSM services – 1

- Voice transmission
 - speed of codec 13 kbps (later: 5.6 kbps)
 - compromise: poorer quality of voice, but higher utilisation of frequency
- SMS (Short Message Service)
 - max. 160 character (1 character = 7 bits)
- Data transmission
 - originally 9.6 kbps, later 14.4 kbps
 - circuit switched


GSM services – 2

- EMS (Enhanced Messaging Service)
 - simple pictures
- MMS (Multimedia Messaging Service)
 - multimedia message: picture, text, voice together
 - since 2002
- Location Based Services
 - relatively imprecise (cell level!),
 - but it can be told e.g., where is a restaurant nearby

GSM/GPRS

- GPRS (General Packet Radio Service)
 - since 2001
 - packet switched data transmission, extension to GSM
 - advantage:
 - better utilisation of network, frequency
 - payment on basis of amount of transmitted data (kB), not on basis of duration of connection
 - speed
 - originally max. 56 kbps
 - theoretically max.: $8 \times 20 = 160$ kbps
 - typically 60-80 kbps downlink, 20-40 kbps uplink
 - fewer channels used in uplink direction
 - usage:
 - Internet access
 - requires significant extensions in the network (next slide)

GPRS architecture



GSM/GPRS

CS: Circuit Switched Subsystem

PS: Packet Switched Subsystem

- SGSN: Serving GPRS Support Node
- GGSN: Gateway GPRS Support Node (to other data networks e.g. Internet)
- BG: Border Gateway (gateway to other GPRS service providers)
- CG: Charging Gateway